



JBM - 54037 - ESTUCHE DE HERRAMIENTAS DE 108 PIEZ

El estuche contiene:

Carracas

- Carraca de 72 dientes 1/2" (255 mm)
- Carraca de 72 dientes 1/4" (145 mm)

Adaptadores

- Adaptador de cabezales hex. 1/2" x 8 mm
- Adaptador 3/8" hembra - 1/2" macho

Vasos hexagonales 1/2" (75 mm largo): 14 mm, 15 mm, 17 mm, 19 mm, 22 mm

Vasos hexagonales 1/2" (cortos): 10 mm, 11 mm, 12 mm, 13 mm, 14 mm, 15 mm, 16 mm, 17 mm, 18 mm, 19 mm, 20 mm, 21 mm, 22 mm, 24 mm, 27 mm, 30 mm, 32 mm

Vasos TORX (TX) 1/2": E10, E11, E12, E14, E16, E18, E20, E24

Vasos para bujía hex. 1/2": 16 mm, 21 mm

Barras de extensión 1/2": 125 mm, 250 mm

Articulación universal

- 1/2"
- 1/4"

Mangos

- Mango destornillador 1/4"
- Mango corredizo (T) 1/4"

Barras de extensión 1/4": 50 mm, 100 mm

Vasos destornillador (1/4")

- Phillips (PH): 1, 2
- Pozidriv (PZ): 1, 2
- Hexagonal: 3 mm, 4 mm, 5 mm, 6 mm
- Plano (SL): 4 mm, 5.5 mm, 6.5 mm
- TORX (TX): T8, T10, T15, T20, T25, T27, T30

Vasos hexagonales 1/4" (cortos): 4 mm, 4.5 mm, 5 mm, 5.5 mm, 6 mm, 7 mm, 8 mm, 9 mm, 10 mm, 11 mm, 12 mm, 13 mm, 14 mm

Vasos hexagonales 1/4" (50 mm largo): 6 mm, 7 mm, 8 mm, 9 mm, 10 mm, 11 mm, 12 mm, 13 mm

Vasos TORX (TX) 1/4": E4, E5, E6, E7, E8

Puntas Allen 8 mm

- Hexagonal: 7 mm, 8 mm, 10 mm, 12 mm, 14 mm
- Plano (SL): 8 mm, 10 mm, 12 mm
- Phillips (PH): 3, 4
- Pozidriv (PZ): 3, 4

- TORX (TX): T40, T45, T50, T55, T60
- XZN: 5 mm, 6 mm, 8 mm, 10 mm, 12 mm

Llaves Allen: 1.5 mm, 2 mm, 2.5 mm







